

DEMCO TOW BAR BASE PLATES

In Section P:

Roadmaster Brackets

Demco Base Plates

Blue OX Base Plates



DEMCO BASE PLATES FOR TOW BARS

SEE PAGE 530 FOR DEMCO TOW BARS

Demco Base Plates bolt permanently to the chassis of your vehicle, providing a secure, reliable attachment point for the Demco Tow Bar.

Base Plates are NOT INCLUDED with the Demco Tow Bar; they must be ordered separately.

Definition of letter codes used in the following table:

A- Estimated Installation Time (hours)*7 – B - Shipping Weight (lbs) –

C - Width Between Attaching Ears on Base Plate, Center to Center (inches) – D - Base Plate Attaching Pin Height, Approximate (inches)

Limited Supply

DEMCO TOW BAR BASE PLATES

Order #	Mfr. #	Year (s)	Make	Model(s)	A	B	C	D
39171	#9517127	02-06	Cadillac	Escalade & ESV*4; 02-05 Escalade EXT*4	1	35	30	16
34861	#9517042	04	Chevrolet	Malibu Classic*4*9; 97-03 Malibu*4*9	3	30	24 1/8	14 1/4
38937	#9517079	99-04	Chevrolet	Tracker, (2 or 4 door & ZR2)*9	3	34	22 1/2	16 3/4
39408	#9517148	03	Chevrolet	Pick-Up (2WD & 4WD) 1500 HD*4	1	30	30 3/4	17 1/2
39408	#9517148	03-06	Chevrolet	Pick-Up (4WD) 2500 HD, 2500 & 3500*4	1	30	30 3/4	17 1/2
39408	#9517148	07-08	Chevrolet	Pick-Up (4WD) 2500 HD Classic*4	1	30	30 3/4	17 1/2
30490	#9517169	04-07	Chevrolet	Malibu & Malibu Maxx*4*9; 08 Malibu Classic*4*9	3	34	24	14
30489	#9517134	02-05	Dodge	Ram 1500 Pick-Up (2WD & 4WD) (Includes Sport)*4*9	1	15	26	24
30489	#9517134	06	Dodge	Ram 1500 Pick-Up Mega Cab (2WD & 4WD)*4*9	1	15	30	24
30489	#9517134	03-10	Dodge	Ram 2500 & 3500 Pick-Up (2WD & 4WD)*4 (Includes Mega Cab & Diesel)	1	15	30	24
39401	#9517141	02	Dodge	Stratus 2 door*4	3	38	24	14 1/2
39168	#9517120	02-05	Ford	Explorer 4-Door (All models) *4*9	2	30	27 5/8	15 1/2
39171	#9517127	01-06	GMC	Pick-Up (4WD) Sierra Denali 1500 Series *4	1	35	30	16
39171	#9517127	01-06	GMC	Pick-Up (4WD) Sierra Denali 1500 Series Classic*4	1	35	30	16
39171	#9517127	01	GMC	Sierra C3*4	1	35	30	16
39171	#9517127	01-06	GMC	Yukon Denali XL*4	1	35	30	16
39171	#9517127	01-06	GMC	Yukon Denali *4	1	35	30	16
39408	#9517148	03-04	GMC	Pick-Up (2WD & 4WD) 1500 HD*4	1	30	30 3/4	17 1/2
39408	#9517148	03-06	GMC	Pick-Up (4WD) 2500 HD & 3500*4	1	30	30 3/4	17 1/2
39408	#9517148	07-08	GMC	Pick-Up (4WD) 2500 HD & 3500*4	1	30	30 3/4	17 1/2
39376	#9517135	02-04	Honda	CR-V*4*9	2	25	22 1/2	19 1/2
39376	#9517135	03-08	Honda	Element (Not SC)*3*9	2	25	22 1/2	19 1/2
30492	#9517180	05-06	Honda	CR-V*4*9	2	25	22 1/4	19 1/2
37418	#9517011	93-98	Jeep	Grand Cherokee*9	2	33	24	17
37418	#9517011	93-94	Jeep	Grand Wagoneer*9	2	33	24	17
30488	#9517112	Older-96	Jeep	Jeep & Jeep CJ*9	1	7	24	-
39170	#9517126	02-04	Jeep	Liberty (All models)*4*9	2	27	22 1/4	18
39169	#9517125	02-05	Mercury	Mountaineer *4	2	30	24	13 1/2
34861	#9517042	97-99	Oldsmobile	Cutlass*4*9	3	30	27 1/8	14 1/4
38931	#9517066	99-04	Pontiac	Grand Am (Includes GT)*4	3	40	27	14 1/2
37415	#9517008	93-94	Saturn	SC2	4	60	24	14
39405	#9517145	03	Saturn	L200, L300, LW200, LW300*4	3	40	25 1/2	14
39405	#9517145	04-05	Saturn	L300, LW300 All Models*4	3	40	25 1/2	14
38937	#9517079	99-03	Suzuki	Vitara (2 or 4-door)*9	3	34	22 1/2	16 3/4
30707	#9517197	06-08	Suzuki	Grand Vitara*4*9	3	25	24	20 1/2

Demco Base Plates Footnotes: – *1- Prices are "Suggested Retail Prices". – *2-Not available at time of printing. – *3-Baseplate is concealed through the air dam. – *4-Baseplate is concealed through the bumper opening. – *5-If 97, 98, 99, or 00 SC2 is equipped with running lights, they need to be relocated per instructions. – *6 - If equipped with optional Mopar Tube Bumper. –

*7 - Installation times based on a shop with hoist and proper tools. *8 - Baseplate is concealed through fog light holes.

*9 - Baseplate is adaptable to Blue Ox tow bars with a 3-prong clevis.

Demco Base Plates bolt permanently to the chassis of your vehicle providing a secure, reliable attachment point for the Demco Tow Bars.